

PRODUCT NO. 494800



Wheel Weight Remover

SPRAY ON GEL

Formulated to remove gasket adhesive left behind after wheel weight removal prior to wheel balancing.

FEATURES & BENEFITS

- Removes stuck-on wheel weight gasket adhesive
- Thick clinging gel
- Safe on aluminum, alloy, and steel wheels

APPLICATIONS & USES

Use to remove all wheel weight adhesive. It can also be used to remove gaskets and thread locking adhesives. Safe on aluminum, alloy, and steel wheels.

DIRECTIONS FOR USE

1. Shake vigorously for one minute after mixing, the ball begins to rattle.
2. Spray 8 to 12 inches from the surface.
3. Allow several minutes to penetrate wheel weight adhesive.
4. Remove wheel weight gasket adhesive with a microfiber towel to prevent scratching surface. Rinse surface.
5. Repeat above if necessary.

CAUTION: May soften some plastics and paints.

SIZE / AVAILABILITY

CAN SIZE: 20 oz
NET WEIGHT: 14 oz
QUANTITY: 12 per case
SHIPPING WEIGHT: 16 lbs

PHYSICAL CHARACTERISTICS	
COLOR	Off White
FRAGRANCE	Pungent
SPRAY PATTERN	Gel
SHELF LIFE	1 Year +
REGULATORY	
OZONE DEPLETING COMPOUNDS	None
RECYCLABLE PACKAGING	Yes
VOC COMPLIANT CARB/OTC	Yes
SHIPPING NAME	Aerosols (LTD QTY)
24 HOUR MEDICAL EMERGENCY	1-866-836-8855